

Deployable Payload Separation Test 1

March 17, 2018

Separation Test Procedures

This document contains the following:

• The procedure for testing the separation mechanism of the deployable payload

Personnel Required

The procedure has no set roles, and as such all members participating in the test will be referred to as **OPERATOR**

Prior to Start

1	☐ Items to be completed before beginning procedure
2	\square Connect up the cubesat rigging
3	$\ \square$ Make sure you have a clear table and workspace with no nearby people
4	$\ \square$ Make sure all participants in the test are wearing safety glasses for the duration of the test
5	☐ Make sure the test is conducted outside
6	$\ \square$ Make sure you have a deployment charge prepared according to the corresponding SOP
7	☐ Make sure the batteries are disconnected from the stratologger and arduino, and no wires are connected to the MAIN or DROGUE terminals of the stratologger

	Test Procedure
1	□ OPERATOR Lay the nose cone on the table with the tip pointed away from any personnel. Ensure that during the entire procedure the area in front and behind the nose cone always remains clear. Treat the system as armed for the entire procedure
2	□ OPERATOR Lay the cubesat on its side on the table behind the nose cone
3	\Box OPERATOR Remove the 8 screws holding the cubesat side plate in place and set aside
4	□ OPERATOR Ensure that the batteries are disconnected from the stratologger and arduino
5	$\hfill \Box$ OPERATOR Grab one of the pre-assembled CO2 charges and zip-tie it to the Nylon tape, roughly 1 foot above the eyebolt of the cubesat
6	\square OPERATOR Wrap a fireproof cloth around the mount to protect the rigging from gunpowder
7	\Box OPERATOR Run the charge wire through the hole on the top of the cubesat and connect to the stratologger screw terminal marked DROGUE
8	\Box OPERATOR Connect the arduino and stratologger battery. At this point you have 15 minutes until the stratologger is armed
9	\Box OPERATOR If the stratologger begins the arming procedure (Buzzer goes off) there are about 20 seconds before the stratologger is armed
10	\square Immedietly stop all work and step away from the table
11	$\hfill \square$ Make sure the area in front and behind the nose cone assembly are clear
12	\square Wait 10 minutes for the arduino to automatically disarm the stratologger
13 14	\square Once the buzzer stops disconnect the battery from the stratologger and arduino \square Restart the procedure
15	\square OPERATOR Replace the removed panel from the cubesat and fasten the 8 screws
16	□ OPERATOR Place the parachute in the nose cone
17	□ OPERATOR Place the rigging in the nose cone
18	\Box OPERATOR Slide the cubesat into the nose cone, ensuring that the rigging is not interfering with the cubesat
19	\Box OPERATOR Place the recovery top coupler over the bottom of the nose cone assembly
20	\Box OPERATOR Attach the 3 shear pins that connect the recovery coupler to the nose cone assembly
21	□ OPERATOR Take the combustion chamber thrust mount and lay it horizontal
22	$\hfill \Box$ OPERATOR Place the nose cone in the thrust mount, ensure that the recovery top coupler is in the mount clamp
23	□ OPERATOR Tighten the mount clamp such that it only grips the recovery top coupler
24	□ OPERATOR Connect the vacuum pump hose to the hole in the base of the recovery top coupler
25	\square OPERATOR Stand back, ensuring that the area in front and behind the assembly is clear
26	□ OPERATOR Turn on the cameras filming the test
27	\Box OPERATOR Wait for the arming procedure to begin and complete, when ready you should hear a beep

once per second indicating good drogue continuity

28	□ OPERATOR Turn the vacuum pump on for 5 seconds
29	□ OPERATOR Shut off and wait for deployment event
30	\Box OPERATOR Wait for the buzzer to stop, indicating that the system is no longer armed
31	□ OPERATOR Separate the cubesat from the nose cone
32	□ OPERATOR Remove the cubesat side panel
33	□ OPERATOR Disconnect the stratologger and arduino batteries
34	□ OPERATOR Proceed with disassembly